



SHAFTALIGNMENT.HAMARLASER.COM



- Dual-Beam™ Unidirectional Laser Technology
- 5-Year Unconditional Warranty
- Calibration Requirement Every 2 Years
- Ultra Accuracy for Fast Alignments

- No Rough-in Needed
- Duo-Plane™ Live Move Screen
- 6 Data Taking Methods Available
- 8 Alignment Methods Available



Unmatched Angular Accuracy and Repeatability

The world's most advanced shaft alignment technology

For over 50 years, Hamar Laser has been providing highly accurate alignment systems to many different industry and application needs. We started with machine tooling where tolerances are high and applications are difficult, then in 1990, we developed the world's first 4-axis shaft alignment system. All that experience and knowledge has gone into the X-880 Wireless 5-Axis Shaft Alignment System, resulting in the most accurate and easy-to-use laser aligner in the world.

No rough-ins needed with the X-880

X-Series[™] patented Dual-Beam[™] Unidirectional Technology removes the need for rough-ins of the equipment during a pre-alignment check. Every other alignment system requires a rough-in of the machine before the system can take data. Unlike competing systems, with the X-880's 2 unidirectional laser beams and 33-mm sensor, the technician is not required to perform a rough-in before starting an alignment. You get the same measuring range from 2 in. to 33 ft. (50 mm to 10.06 m), just slap on the laser and target and get to work!

Fixed angular measuring resolution

What sets the X-Series[™] apart is the angular accuracy and repeatability of our systems. With other laser technologies, the angular resolution varies with distance, the closer a coupled application is, the worse the angular accuracy for these systems become. With our Dual-Beam[™] technology, the X-880 provides the same high angular resolution at 1 in. (25 mm) between heads as you get at 33 ft. (10.06 m), which is 15x higher than the highest angular specification.

Revolutionizing Precision Alignment with X-SERIES™



Advanced Unidirectional Dual-Beam[™] Technology

This innovative technology provides an amazing $\pm 12^{\circ}$ of angular range. Utilizing 2 unidirectional laser beams (2 lasers, 1 direction), the X-880 solves the rough-in problem with "cross-fire" lasers (2 lasers, 2 directions), makes aligning machines amazingly fast and easy, especially on long-distance applications. The result? More jobs done in less time and happier managers!

Alignment Methods with the X-880 5-Axis System











(Included) Standard Machine Alignment aligns two rotating machines connected by a single coupling. Includes measuring and correcting angular and offset misalignments between machine shafts to achieve optimal alignment.

(Included) Vertical Motor Alignment is the industry's only vertical alignment with live graphical displays of the motor's alignment along with shim values for all bolthole locations. This alignment is for flange-mounted vertical motors.

(Optional) Spacer (Jack) Shaft Alignment aligns the shafts of two rotating machines that are connected by a spacer or jack shaft to ensure their rotational centerlines are collinear. There are 7 different formats that can be used in this type of alignment.

(Included) Bolt/Base Bound Alignment lets you lock/unlock different combinations of the moveable and stationary machine feet to see how it affects the alignment solution. The graphics and shim values automatically update.

(Included) Machine Train Alignment lets you take data from 3 to 10 machines and will calculate the shims/ moves that minimizes the moves. This ensures that all shafts are collinear and properly aligned throughout the entire train.



Add Geometric Laser Alignment without changing software, laser, or target!

Turn your X-880 into a Geometric Alignment System. Utilizing the X-880 Laser and Target, perform Manual or Timed Data Recording, Flatness, and Straightness Measurements in Couple6.



Data Taking Methods with the X-880 5-Axis System



Auto Clock[™] Mode has 8 clock positions to choose from, simply rotate the laser/target to that position, and click record. Minimum three points in 90-degrees needed.



Auto Sweep[™] Mode starts at any clock position and sweeps to any other point with a minimum of 60 degrees. This mode auto-calculates when the sweep is stopped.



Uncoupled Swipe makes taking data much easier. Rotate the laser to any clock position, sweep the target past it, where it automatically records the data point.



Arc Mode[™] starts and stops at any point in the rotation circle multiple times. Use where there are obstructions that block the laser beam or prevent a full rotation.



Point Mode rotates the laser/target to any clock position in the rotation and records a data point at that location. Also used to perform uncoupled alignments.

Revolutionizing Precision Alignment with X-SERIES™

Easy-Guide™ Software Makes Navigation Simple

Our Couple6 software is every bit as brilliant as our hardware, featuring our Easy-Guide[™] navigation with its easy-to-follow, high-quality color screens that makes even the novice user look like an expert! Whether using our optional 10 in. (254 mm) Rugged Windows[®] tablet or placing Couple6 on a company laptop or tablet, just follow our 5-step process that guides you through each stage of the alignment and before you know it, you're printing a report!



Couple6 Software Steps for the X-880 5-Axis System



Project Menu starts new projects on a new or existing machine, manages old alignment projects, reviews saved files, creates project templates, and accesses optional apps. Creates a unique machine folder that stores all the alignments in one place for easy historical analysis.



Step 2 - Laser Setup Screen provides live, 4-axis, raw alignment data to initialize the system and maximize measurement range. On-screen graphics show you which direction to move the laser and target during the setup. Can also be used for new-motor pre-alignment.



Step 1 - Machine Type, Dimensions & Tolerances is where you select your shaft alignment method, machine and coupling type, enter dimensions, and select tolerances by RPM or enter user-defined tolerances. Thermal Growth compensation is accessed from this step.



Step 3 - Soft Foot Check provides an on-screen, easy-to-follow procedure for checking Soft Foot, a common problem that can cause many alignment problems. By placing it in the process, it removes this step in the pre-alignment checklist. Automatically selects the "problem" foot and calculates the shim to fix it.



Step 5 - Move and Shim utilizes our Duo-Plane[™] live move screen to show both the side and top views of the motor's alignment and displays 4 continuously updating alignment axes (2 alignment planes) on the same screen. Arrows on the display shows which way to move the motor in real-time.





Step 1 - Thermal Growth lets you enter thermal growth values at the coupling or the feet to offset the alignment at the move stage; the motor graphics will auto update. Or enter temperature changes at the feet, select the material and Couple6 calculates the alignment at the coupling.



Step 4 - Measure Misalignment makes coupled alignment amazingly easy. With 5 data-taking modes available and with the built-in accelerometer, Couple6 detects shaft rotation and, depending on the mode, records data in a clock, arc, uncoupled, point, or sweep. More data points means better accuracy and quicker alignments.

Print Reports uses the power of Windows[®] 10/11. Couple6 can print to any printer, and save a PDF file or XPS file for emailing or texting reports. With the optional App, Image Capture, you can add up to 10 images to the report. You can also choose to include or not include Soft Foot Check display, Thermal Growth Data or Data Taking History.

Revolutionizing Precision Alignment with X-SERIES™



L-790 Dual-Beam™ Laser

- 2 Unidirectional, parallel laser beams that can be used out to 30 ft. (10 m), which are much safer than the competitor 6° fans that can be up to 3 ft. (1 m) wide at 30 ft.
- Horizontal laser beam adjustment for faster setups.
- 2 mm diameter laser beams allows for extra measuring range.
- Blinking lasers for ambient light correction.

T-1290 Wireless 5-Axis Target

- 2-Axis 33(V) x 13(H) mm PSD with .00002 in. (0.0005 mm) resolution
- Measurement accuracy of:
 - Offset Error < 0.15%
 - Angular Error <.75%
- ±.59 in. (±15 mm) offset measuring range
- ± 12° angular measuring range
- Rotation axis 0.1°. resolution with ±1.0 ° accuracy.
- Bluetooth Class I wireless communication with • range of 100 feet (10 m).

A-980 Stainless Steel Shaft Brackets

- Stainless steel quick-connect brackets for fast setup and stable readings.
- For shaft diameters from .8 to 6.0 in. (20-152 mm)
- 2 sets (qty 4) 4 in. (152 mm) and 8 in. (304 mm) posts.
- Stainless steel chain with magnetic tip to secure extra chain and protect the equipment.
- A-980A Chain Bracket Upgrade with chains to handle up to 12 in. diam. shafts and 6 in. (152 mm) and 12 in. (304 mm) posts.
- Fits into carrying case with posts connected. •

- Common charging cable for both laser and target.
- IP67 waterproof housing allows it to be submerged in water up to 3 feet (1 m) and still transmit data!
- Operating range of 30 feet (10 m) from laser to target.
- 125-hour battery life. Can be operated while plugged into A/C charger.
- Laser-On and Low Battery LED's.
- IP67 waterproof housing allows it to be submerged in water up to 3 ft. (1 m) and still transmit data!
- 15-hour (continuous) battery life. •

With our

10" (254

Windows®

Tablet, our

Couple6

software

operates

- Wireless Link, On-Target, Data Communication and Low Battery LED's.
- USB charging cable also can be used as data communications cable in case of wireless problems.



along with any other software you have that is on the Windows[®] Platform. With batterv hot-swap, wi-fi access, and unlimited storage via a cloud network, this tablet meets all your needs and can be easily replaced if something happens to it.

Additional Accessories for the X-880 5-Axis System



A-982 Magnetic Bracket



A-980 D - Chain Set 1-20 In. (25-508 mm)



A-980OF - Offset Bracket 1 in. (25.4 mm)



A-980E - Bracket Posts -6 & 12 in. (152 & 304.8 mm)



A-980NRA-1 - Non-Rotating Shaft Bracket System





X-880 System Specifications

Laser/Target Unit Size	4.2 x 3.3 x 2.2 in. (107 x 84 x 55 mm)	
Housing Material	Impact resistant plastic	
Detector Type & Size	2-axis super-linear PSD 33 mm (V) x 13 mm (H) provides 4 continuously updating alignment axes (or 2 alignment planes).	
Ambient Light Protection	Via blinking-laser algorithm embedded in all Hamar Laser targets.	
Target Measurement Resolution	Offset: .00002 in. (0.0005 mm) Angular: .00008 in/ft (0.007 mm/m)	
Target Measurement Error	Offset: <0.15% Angular: <0.75%	
Angular Sensor Range	\pm 12° (± .204 in/in or 20.4 mm/100 mm). For values > 5°, use only for rough alignment.	
Laser Type	650 nm unidirectional Dual-Beam laser with horizontal adjustment <0.9mW	
Communication between Target & Data Analyzer	Wireless Bluetooth® Class $2 - 2.4$ Ghz	
Wireless Range	Up to 100 ft. (30.48 m)	
Ruggedized Display Platform	Industrial tablet with 10 in. (254 mm) touchscreen. MIL-STD-810H and MIL-STD-461G certified	
Rotation Sensor (5th axis)	Accelerometer Resolution: 0.1° Accuracy: ±1°. Measurement accuracy not affected by rotation sensor accuracy.	
Environmental	IP67 (laser & target). IP65 (tablet) rated	
Bracket Set	Covers .79 in. (20.0 mm) to 6 in. Comes with 4 in. (101.6 mm)	(152.4 mm) diameter shafts.
Application Range	33 ft. (10.06 m) between laser and target	
Operating/Storage Temperature	Laser/Target: Tablet - AC Mode: Tablet - Battery Mode:	5°F to 140°F (-15°C to 60°C) -4°F to 140°F (-20°C to 60°C) 32°F to 113°F (0°C to 45°C)
Battery Life – Target	14 hours continuous use with Bluetooth®, 15 hours with data communications cable. Target can be plugged into power source during use. Battery status indicator for both Target and PC.	
Battery Life – Laser	150+ hours continuous use. Blinking LED indicates low battery status	
Battery Life – Tablet	8 hours, best power efficiency setting	
AC Battery Charger Laser and Target	110V-240V with U.S. and international adapters. Charging cable is also the data backup cable	





Included Couple6 Apps

- Data Quality Analyzer •
 - Flip It™
- Machine Templates •
- Printed Reports •

•

- Recommended Tolerances 2 levels
- Auto Clock[™] Data Taking -
- **Digital Signature Capture** .
- Horizontal/Vertical Machines •
- Save Data/Database Management •
- Soft Foot Check
- **Machine Templates** •
- Thermal Growth Calculator (@feet) .
- User-Defined Tolerances •
- Vertical Machines Live Move
- Auto Sweep[™] Data Taking
- Bolt/Base Bound[™] •
- Data Recorder (Timed/Manual) •
- Machine Train-3
- Repeatability/History •

Optional Couple6 Apps

- Thermal Growth (@coupling) •
- Machine Image Capture (reporting)
- Arc Mode™ Data Taking •
- Uncoupled Swipe Data Taking .
- Point Mode Data Taking •
- Spacer Shaft 7 Formats
- Machine Train-10
- Geo Manual/Timed Data Recorder/Analyzer
- Geo Flatness Data Recorder/ Analvzer
- Geo Straightness Data Recorder/ Analyzer



Hamar Laser Instruments, Inc. 5 Ye Olde Road, Danbury, CT 06810 P: +1.800.826.6185 F: +1.203.730.4611 sales@hamarlaser.com www.hamarlaser.com



NO WORRIES MANUFACTURER'S WARRANTY

